

FRICITION COLLAR

Fast, easy and does not require anchors.

Alsina



■ Description

System used with prefabricated columns or columns in which anchors are not intended to be left within them. Thanks to its design, it can support high loads transferred by the slab system, working in friction with the column.

■ Components and accessories

- Prestressed and positioning bolts.
- Adjustable head.
- Adapters to separate the head from the column.

■ Frequent uses

- Execution of horizontal elements on circular columns.

■ Properties

- High quality prestressed bolts that allow the system to exert pressure on the column.
- Adjustable head system that allows adapting to the height and releasing the system following execution.
- Adapters are included to separate the head from the column when there are beams that exceed the width of the column.
- System positioning bolts that allow safe and quick assembly.